

OUC BACKFLOW PREVENTION REQUIREMENTS

ABBREVIATIONS:

- RPDA** Reduced Pressure Detector Assembly
RPZ Reduced Pressure Zone
DCVA Double Check Valve Assembly

***Note: RPDA are to be used on non-metered fire services.**

RESIDENTIAL (POTABLE WATER SYSTEMS)

- RPDA** Fire Sprinkler System with chemical additives or any other hazardous materials
RPZ Any irrigation system equipped with chemical injection
DCVA Any irrigation system without chemical injection used in areas with reclaimed water available

ALL OTHERS

- RPDA** All non-metered fire services
RPZ All other services

Note: For 6" devices or larger, please email backflowtesting@ouc.com to schedule a meeting.

Questions or Comments?
Contact OUC Backflow Department
at backflowtesting@ouc.com